


BOOTSIE CHAIR INSTRUCTIONS


For additional help during installation of your bootsie chair , visit currentluxury.com/dealer-resources/ or call 1-844-307-7435.

1. The Bootsie chair is ready to use when unboxed. When you unfold your Bootsie chair it will automatically lock to ensure against folding while in use. To fold the chair locate the lock mechanism on the right rear of the chair, push the “Press To Unlock” button.
2. To adjust the tension on the reclining feature locate the adjustment knob at the rear of the chair. Turn knob towards the + to increase resistance, turn knob to – to decrease resistance. Please note it may take few full turns of the knob to find the perfect setting.



BOOTSIE TRAY/CUP HOLDER INSTRUCTIONS

For additional help during installation of your bootsie chair , visit currentluxury.com/dealer-resources/ or call 1-844-307-7435.



1. You can utilize the Tray/Cupholder on either side of the Bootsie chair. To install place the open end below the chair arm onto the frame and slide down.
2. To store your Tray/Cupholder remove it from the chair, after folding the Bootsie snap onto the carrying handle frame with the open end up.

