








INSTALLATION GUIDE

HALO BASE INSTRUCTIONS.....	Page 2
HALO UMBRELLA ASSEMBLY.....	Page 3
HALO FULL LED PROGRAMMING INSTRUCTIONS.....	Page 4
HALO TOP LED PROGRAMMING INSTRUCTIONS.....	Page 5
HALO NO LED PROGRAMMING INSTRUCTIONS	Page 6
UMBRELLA REMOTE INSTRUCTIONS.....	Page 7
UMBRELLA CANOPY COVER INSTRUCTIONS.....	Page 8

BASE INSTRUCTIONS

For additional help during installation of your Halo umbrella, visit currentluxury.com/dealer-resources/ or call 1-844-307-7435.



BILL OF MATERIALS		
ITEM NO.	Description	QTY.
1	BASE	1
2	TIGHTENING SCREW	2
3	ALIGNER	1
4	BASE STAND	1
5	BOLT	4
7	ALLEN KEY	1


1. Place base stand aligner underneath the base stand and place base stand onto base making sure to align holes of the base stand with the holes on the base.

2. Screw hex drive bolt into the base to connect the base stand to the base. (tool included).

HALO UMBRELLA ASSEMBLY


For additional help during installation of your Halo umbrella, visit currentluxury.com/dealer-resources/ or call 1-844-307-7435.

**Current Luxury does not recommend using the Halo umbrella in any application that the product is not safely secured in an appropriate base or a table. Failure to adhere to proper use will cause product damage.*




HALO WITH UPPER AND LOWER LED LIGHTING CONTROL INSTRUCTIONS

For additional help during installation of your Halo umbrella, visit currentluxury.com/dealer-resources/ or call 1-844-307-7435.




1. To open/close the umbrella gently press on the lower lighting shroud until movement occurs, then remove your hand.(approximately 3 seconds)
2. Press and release the lower lighting shroud momentarily to turn on the LED lighting system, continue to press and release the lighting shroud to use all dimmable settings or until LED lighting system turns off. The lights will automatically go off when the umbrella closes.
3. The Halo umbrella is a solar powered device but if it has been stored or not in direct sunlight you can easily charge your Halo umbrella by locating the charging port below the light shroud on the canopy pole and plugging in the charger provided, should take 4-6 hours for full charge.

**Current Luxury does not recommend using the Halo umbrella in any application that the product is not safely secured in an appropriate base or a table. Failure to adhere to proper use will cause product damage.*



HALO WTH UPPER LED LIGHTING ONLY CONTROL INSTRUCTIONS


For additional help during installation of your Halo umbrella, visit currentluxury.com/dealer-resources/ or call 1-844-307-7435



1. To open/close the umbrella push the bottom button located on the canopy pole.
2. Press the top button to turn on the LED lighting, continue to push for each dimmable light setting or to turn off LED lighting system.
3. The Halo umbrella is a solar powered device but if it has been stored or not in direct sunlight you can easily charge your Halo umbrella by locating the charging port between the buttons on the canopy pole and plugging in the charger provided, should take 4-6 hours for full charge.

HALO (NO LED) CONTROL INSTRUCTIONS


For additional help during installation of your Halo umbrella, visit currentluxury.com/dealer-resources/ or call 1-844-307-7435.



1. To open/close the umbrella push the bottom button located on the canopy pole.
2. The Halo umbrella is a solar powered device but if it has been stored or not in direct sunlight you can easily charge your Halo umbrella by locating the charging port between the buttons on the canopy pole and plugging in the charger provided, should take 4-6 hours for full charge.

UMBRELLA REMOTE INSTRUCTIONS

For additional help during installation of your Halo umbrella, visit currentluxury.com/dealer-resources/ or call 1-844-307-7435.



1. Pull plastic tab from the remote base,

2. Put Halo umbrella into learn mode.

(2a) HALO WITH UPPER AND LOWER LED LIGHT

1. Press and hold the light shroud until it beeps.




(2b) HALO WITH UPPER LED LIGHT ONLY

1. Press and hold the lower button on the umbrella (close/open) until it beeps.

(2c) HALO WITH NO LED LIGHT


1. Press and hold the button on the umbrella (close/open) until it beeps.

3. Press and release the button on the back of the dog bone remote with the pin tool or paper clip. Immediately after pressing the button the back of the remote. Press and release the up button on the front of the remote. The umbrella will jog to confirm that it is programmed to the remote.



UMBRELLA COVER INSTRUCTIONS

For additional help during installation of your halo umbrella, visit currentluxury.com/dealer-resources/ or call 1-844-307-7435.



1. To protect your Halo umbrella when not in use, place the cover over the top of the Helux canopy using the fiberglass extension rod located inside the cover. Once covered simply pull down on the zipper using the cords attached.